





### Unvented hot water cylinders and boilers

- Immersion probe screwed into the vent pipe




### Toilet ducts / Service and wet cores

- Water sensing probes or sensing cable placed where a leak would go unnoticed





### Tea point / Vending area / Kitchen

- Water sensing cable, installed in the raised floor void or beneath units




#### Soil / Waste vent pipe

- Immersion probe, inserted into the pipe to detect a back-up caused by a blockage




#### Horizontal overflow pipe / Tank / Swimming pool / Discharge lines (not suitable for foul drainage)


- Immersion probe, inserted into the bottom of the pipe to detect a flow of liquid or a back-up caused by a blockage



#### Pipe in pipe / Dual containment

- Sensing cable installed in the interstitial space between two pipes







**Sump / Pit monitoring /  
Lift pits / Cable entry / Basements**

- Water sensing probes or sensing cable placed at the base of a sump or at a level where you would require detection


**Tank level (high/low) or over flow indication**

- Immersion probe inserted into the side of the tank for high level indication
- Float switch inserted into the side of the tank for high and low level indication
- Water Sensing probe or sensing cable placed around the base of a tank or within a drip tray / bund



**Pipe trench / Service duct / Undercroft**

- Water sensing probe or sensing cable placed below the manhole or access cover within a pipe trench



### Alarm and Location


- Monitors for water, fuel oil, chemical and refrigerant gas leaks in many different rooms and floors at any one time
- Locates a leak to within 1 metre anywhere on the system
- Sections of sensing cable and probes covering one area / room can be given a name or identification "ID"
- Simultaneously monitors up to 127 SIM controllers (slave units)
- Can be connected directly to solenoid valves, pumps and external remote alarm devices

### Multi Zone Alarm

- For up to 8 individual sensing zones, for multiple sensors / areas / floors
- Alarm relay outputs can control individual, pumps, valves, air-conditioning units in separate zones


### Single Zone Alarm

- For single and small area coverage
- 12, 24 and 230 volt panels and controller to suit the application
- Alarm contacts connect to BMS, speech & auto-diallers, pumps and solenoid valves for remote indication and isolation



### Sensing Cables

- Designed to detect water, fuel oils, chemicals or solvents
- Detects presence of the liquid at any point along its length
- Conductive polymer coated sensor wires give 20 year corrosion-free life
- Designed without a braided construction to be quick drying
- Designed for use with all TraceTek and Aquitrone™ alarm panels




### Water Probe Detection

- Floor or wall mounted height adjustable to compensate for uneven floors or 'damp-wet' areas
- For plant rooms, bunds, drip-trays, gullies or gutters
- Use with any of the TraceTek and Aquitrone™ alarm panels

### Immersion probe

- Capable of detecting all conductive liquids (water, coolants)
- Designed for use with all TraceTek and Aquitrone™ alarm panels
- No separate power supply required
- Fitted into overflow pipes, discharge lines, tanks to detect leaks, blockages or overflows



### Float Switches

- Floats available to monitor different liquids using a variety of float materials
- Floats can be set to alarm on the rise or fall of a liquid
- No separate power supply required
- Use with any of the TraceTek and Aquitrone™ alarm panels

**Important:** All information, including illustrations, is believed to be reliable. Users, however, should independently evaluate the suitability of each product for their application. Aquilar Limited makes no warranty as to the accuracy or completeness of the information, and disclaims any liability regarding its use. The only obligations of Aquilar Limited are those in the Aquilar Standard Terms and Conditions of Sale for this product, and in no case will Aquilar Limited be liable for any incidental, indirect, or consequential damages arising from the sale, resale, use or misuse of the product. Specifications are subject to change without notice. In addition, Aquilar Limited reserves the right to make changes - without notification to Buyer - to processing or materials that do not affect compliance with any applicable specification.

Aquitrone is a trademark of Aquitrone Limited  
 Aquilar is a trademark of Aquilar Limited  
 TraceTek is a trademark of Tyco Thermal Controls

**Aquilar Ltd**  
 Weights & Measures House  
 20 Barttelot Road, Horsham  
 West Sussex, RH12 1DQ, UK  
 Tel: +44 (0)1403 216 100  
 Fax: +44 (0)8707 940 320

E-mail: [info@aquilar.co.uk](mailto:info@aquilar.co.uk)  
[www.aquilar.co.uk](http://www.aquilar.co.uk)