

AquiTron | AT-G-ADAPTER

AT-G-ALERT / AT-GSC-16 Adapter



**INSTALLATION
INSTRUCTIONS**



aquilar
leak detection solutions

AT-G-ADAPTER

AT-G-ALERT / AT-GSC-16 Adapter

The document illustrates how to install the AT-G-ADAPTER. The adapter is used with the AT-GSC-16 panel and the AT-G-ALERT sensors.

A. INSTALLATION

The adapter is fitted on RELAY 1 of the AT-GALERT sensor just by gently pushing it in the connector. The adapter is fitted as seen on figure 1.



Figure 1.

Note: The adapter is not polarity sensitive to the cables coming from the AT-GSC-16 panel.

Important: All information, including illustrations, is believed to be reliable. Users, however, should independently evaluate the suitability of each product for their application. Aquilar Limited makes no warranty as to the accuracy or completeness of the information, and disclaims any liability regarding its use. The only obligations of Aquilar Limited are those in the Aquilar Standard Terms and Conditions of Sale for this product, and in no case will Aquilar Limited be liable for any incidental, indirect, or consequential damages arising from the sale, resale, use or misuse of the product. Specifications are subject to change without notice. In addition, Aquilar Limited reserves the right to make changes – without notification to Buyer – to processing or materials that do not affect compliance with any applicable specification.

*AquiTron is a trademark of AquiTron Limited
Aquilar is a trademark of Aquilar Limited*