

TTDM-128 MODBUS

CONNECT AND PROTECT

nVent RAYCHEM TraceTek TTDM-128 System Integration using the MODBUS Protocol

DISCLAIMER: MODBUS map information is proprietary and confidential. Use of this information is permitted solely in order to implement a communications link between customer equipment and nVent RAYCHEM controllers. It may not be used for any other purpose, and it is not to be disclosed to 3rd parties without the written consent of nVent Thermal LLC.

The nVent RAYCHEM TraceTek TTDM-128 Network Master Module provides communication capability to a host system (personal computer, building management system or other automation system) using the MODBUS protocol over an RS-232 or RS-485 serial connection. This document describes briefly the most common system integration method used with a TTDM-128 based leak detection system.

We assume the reader is an experienced Systems Integrator who already understands the MODBUS protocol itself, and that the physical connection (RS-232 or RS-485) between the host system and that the TTDM has already been made. Refer to the TTDM-128 installation instructions H57341 for information on making the host communication connections.

The factory default communication parameters are:

Baud Rate: 9600 (adjustable 600 – 38400)

Parity: None

Stop bits : 1

Data bits: 8

There are many possible leak detection network arrangements using one or more TTDM-128s and/or nVent RAYCHEM TraceTek TTSIM Sensor Interface Modules. The TTDM-128 User Manual H56853 illustrates most of these possibilities. This document assumes that you will be communicating with a single TTDM-128 and that it is connected to a network of one or more Sensor Interface Modules (SIMs or TTSIMs). The TTDM-128 itself incorporates a sensor interface module which is usually set to address 1. Additional external sensor interface modules (TTSIM units) are typically addressed from 2 to 127. Refer to the appropriate nVent RAYCHEM TraceTek module documentation for further information.

For most system integration applications using the TTDM-128, it is only necessary for the host system to scan each leak detection circuit (SIM) for status and leak location information. For each leak detection circuit in the nVent RAYCHEM TraceTek network, the TTDM stores all of the SIM information in an array of 16 Modbus registers. The first of these registers contains the status bits for the SIM. The second register contains the location of the leak in sensor cable resistance units. The Modbus register numbers for these value can be calculated as follows:

Status Register Number (STATUS) = 30101 + 16 * SIM#

Leak Location Register (RLOC) = 30102 + 16 * SIM#

A complete table of register numbers is included in Table 2.

The status register contains details of the operating condition of the sensor cable and the SIM unit. These details are bit mapped into the register value. The following table is a list of the status bits and how they are to be interpreted.

TABLE 1. STATUS REGISTER BIT MAPPING

| Bit # (value) | Meaning | Interpretation |
|----------------------------|-------------------------|--|
| 1 (1) | Leak indication | 0 = no leak, 1 = leak |
| 2 (2) | Sensor contamination | 0 = cable is clean, 1 = contamination (if no leak indication) or leak |
| 3 (4) | Sensor loop intact | 0 = sensor OK, 1 = sensor cable break |
| 4 (8) | Sensor loop balance | 0 = sensor OK, 1 = cable loop imbalance |
| 5 (16) 6 (32) 7 (64) | SIM unit program status | If any of these bits = 1, there is a problem with the SIM unit itself. |

The higher order bits (bits 8 to 16) provide other information about the SIM itself, however these first seven are all that is required to determine the integrity of the leak detection circuit.

Each SIM should be scanned and tested as follows:

1. read the status register (STATUS)
2. test STATUS value for leak indication:
 - LEAK if (STATUS bitand 1)=1 ...i.e., bit 1 is set
 - a. if LEAK, read the location register (RLOC) and calculate the leak location:
 - LOCATION = RLOC / 3.900 ... location in feet from start of sensor
 - or-
 - LOCATION =RLOC / 12.796 ... location in meters from start of sensor
3. test STATUS value for cable and SIM integrity:
 - FAULT if (STATUS bitand 124) <> 0 ... i.e., any one of bits 3~7 is set

If desired additional details can be displayed on the host system by testing the status bits individually and providing appropriate responses. It is usually sufficient for the host system to detect an alarm in the event of a leak or a system fault. A service technician can then go to the TTDM-128 to determine the exact nature of the problem.

TABLE 2. TTDM-128 MODBUS REGISTERS FOR EACH SIM

| SIM# (address) | Function Code | Status Register (STATUS) | Leak Location Register (RLOC) | SIM# (address) | Function Code | Status Register (STATUS) | Leak Location Register (RLOC) |
|----------------|---------------|--------------------------|-------------------------------|----------------|---------------|--------------------------|-------------------------------|
| 1 | 4 | 0117 | 0118 | 23 | 4 | 0469 | 0470 |
| 2 | 4 | 0133 | 0134 | 24 | 4 | 0485 | 0486 |
| 3 | 4 | 0149 | 0150 | 25 | 4 | 0501 | 0502 |
| 4 | 4 | 0165 | 0166 | 26 | 4 | 0517 | 0518 |
| 5 | 4 | 0181 | 0182 | 27 | 4 | 0533 | 0534 |
| 6 | 4 | 0197 | 0198 | 28 | 4 | 0549 | 0550 |
| 7 | 4 | 0213 | 0214 | 29 | 4 | 0565 | 0566 |
| 8 | 4 | 0229 | 0230 | 30 | 4 | 0581 | 0582 |
| 9 | 4 | 0245 | 0246 | 31 | 4 | 0597 | 0598 |
| 10 | 4 | 0261 | 0262 | 32 | 4 | 0613 | 0614 |
| 11 | 4 | 0277 | 0278 | 33 | 4 | 0629 | 0630 |
| 12 | 4 | 0293 | 0294 | 34 | 4 | 0645 | 0646 |
| 13 | 4 | 0309 | 0310 | 35 | 4 | 0661 | 0662 |
| 14 | 4 | 0325 | 0326 | 36 | 4 | 0677 | 0678 |
| 15 | 4 | 0341 | 0342 | 37 | 4 | 0693 | 0694 |
| 16 | 4 | 0357 | 0358 | 38 | 4 | 0709 | 0710 |
| 17 | 4 | 0373 | 0374 | 39 | 4 | 0725 | 0726 |
| 18 | 4 | 0389 | 0390 | 40 | 4 | 0741 | 0742 |
| 19 | 4 | 0405 | 0406 | 41 | 4 | 0757 | 0758 |
| 20 | 4 | 0421 | 0422 | 42 | 4 | 0773 | 0774 |
| 21 | 4 | 0437 | 0438 | 43 | 4 | 0789 | 0790 |
| 22 | 4 | 0453 | 0454 | 44 | 4 | 0805 | 0806 |

| SIM# (address) | Function Code | Status Register (STATUS) | Leak Location Register (RLOC) |
|----------------|---------------|--------------------------|-------------------------------|
| 45 | 4 | 0821 | 0822 |
| 46 | 4 | 0837 | 0838 |
| 47 | 4 | 0853 | 0854 |
| 48 | 4 | 0869 | 0870 |
| 49 | 4 | 0885 | 0886 |
| 50 | 4 | 0901 | 0902 |
| 51 | 4 | 0917 | 0918 |
| 52 | 4 | 0933 | 0934 |
| 53 | 4 | 0949 | 0950 |
| 54 | 4 | 0965 | 0966 |
| 55 | 4 | 0981 | 0982 |
| 56 | 4 | 0997 | 0998 |
| 57 | 4 | 1013 | 1014 |
| 58 | 4 | 1029 | 1030 |
| 59 | 4 | 1045 | 1046 |
| 60 | 4 | 1061 | 1062 |
| 61 | 4 | 1077 | 1078 |
| 62 | 4 | 1093 | 1094 |
| 63 | 4 | 1109 | 1110 |
| 64 | 4 | 1125 | 1126 |
| 65 | 4 | 1141 | 1142 |
| 66 | 4 | 1157 | 1158 |
| 67 | 4 | 1173 | 1174 |
| 68 | 4 | 1189 | 1190 |
| 69 | 4 | 1205 | 1206 |
| 70 | 4 | 1221 | 1222 |
| 71 | 4 | 1237 | 1238 |
| 72 | 4 | 1253 | 1254 |
| 73 | 4 | 1269 | 1270 |
| 74 | 4 | 1285 | 1286 |
| 75 | 4 | 1301 | 1302 |
| 76 | 4 | 1317 | 1318 |
| 77 | 4 | 1333 | 1334 |
| 78 | 4 | 1349 | 1350 |
| 79 | 4 | 1365 | 1366 |
| 80 | 4 | 1381 | 1382 |
| 81 | 4 | 1397 | 1398 |
| 82 | 4 | 1413 | 1414 |
| 83 | 4 | 1429 | 1430 |
| 84 | 4 | 1445 | 1446 |
| 85 | 4 | 1461 | 1462 |
| 86 | 4 | 1477 | 1478 |

| SIM# (address) | Function Code | Status Register (STATUS) | Leak Location Register (RLOC) |
|----------------|---------------|--------------------------|-------------------------------|
| 87 | 4 | 1493 | 1494 |
| 88 | 4 | 1509 | 1510 |
| 89 | 4 | 1525 | 1526 |
| 90 | 4 | 1541 | 1542 |
| 91 | 4 | 1557 | 1558 |
| 92 | 4 | 1573 | 1574 |
| 93 | 4 | 1589 | 1590 |
| 94 | 4 | 1605 | 1606 |
| 95 | 4 | 1621 | 1622 |
| 96 | 4 | 1637 | 1638 |
| 97 | 4 | 1653 | 1654 |
| 98 | 4 | 1669 | 1670 |
| 99 | 4 | 1685 | 1686 |
| 100 | 4 | 1701 | 1702 |
| 101 | 4 | 1717 | 1718 |
| 102 | 4 | 1733 | 1734 |
| 103 | 4 | 1749 | 1750 |
| 104 | 4 | 1765 | 1766 |
| 105 | 4 | 1781 | 1782 |
| 106 | 4 | 1797 | 1798 |
| 107 | 4 | 1813 | 1814 |
| 108 | 4 | 1829 | 1830 |
| 109 | 4 | 1845 | 1846 |
| 110 | 4 | 1861 | 1862 |
| 111 | 4 | 1877 | 1878 |
| 112 | 4 | 1893 | 1894 |
| 113 | 4 | 1909 | 1910 |
| 114 | 4 | 1925 | 1926 |
| 115 | 4 | 1941 | 1942 |
| 116 | 4 | 1957 | 1958 |
| 117 | 4 | 1973 | 1974 |
| 118 | 4 | 1989 | 1990 |
| 119 | 4 | 2005 | 2006 |
| 120 | 4 | 2021 | 2022 |
| 121 | 4 | 2037 | 2038 |
| 122 | 4 | 2053 | 2054 |
| 123 | 4 | 2069 | 2070 |
| 124 | 4 | 2085 | 2086 |
| 125 | 4 | 2101 | 2102 |
| 126 | 4 | 2117 | 2118 |
| 127 | 4 | 2133 | 2134 |

North America

Tel +1.800.545.6258
Fax +1.800.527.5703
thermal.info@nVent.com

Europe, Middle East, Africa

Tel +32.16.213.502
Fax +32.16.213.604
thermal.info@nVent.com

Asia Pacific

Tel +86.21.2412.1688
Fax +86.21.5426.3167
cn.thermal.info@nVent.com

Latin America

Tel +1.713.868.4800
Fax +1.713.868.2333
thermal.info@nVent.com



Our powerful portfolio of brands:

CADDY ERICO HOFFMAN RAYCHEM SCHROFF TRACER